

Restricted Orifice Adapters

0611 O-Ring Boss Pipe Swivel Orifice Adapter



| Part Number | Male ORB | Female Pipe Swivel | Orifice Dia. |
|----------------|----------|--------------------|--------------|
| 0611-08-08-000 | 3/4-16 | 1/2-14 | Un-drilled |
| 0611-08-08-031 | 3/4-16 | 1/2-14 | 0.031" |
| 0611-08-08-062 | 3/4-16 | 1/2-14 | 0.062" |

0616 Female Pipe Swivel Orifice Adapter



| Part Number | Male Pipe | Female Pipe Swivel | Orifice Dia. |
|----------------|-----------|--------------------|--------------|
| 0616-04-04-000 | 1/4-18 | 1/4-18 | Un-drilled |
| 0616-04-04-031 | 1/4-18 | 1/4-18 | 0.031" |
| 0616-04-04-062 | 1/4-18 | 1/4-18 | 0.062" |
| 0616-06-06-000 | 3/8-18 | 3/8-18 | Un-drilled |
| 0616-06-06-031 | 3/8-18 | 3/8-18 | 0.031" |
| 0616-06-06-062 | 3/8-18 | 3/8-18 | 0.062" |
| 0616-08-08-000 | 1/2-14 | 1/2-14 | Un-drilled |
| 0616-08-08-031 | 1/2-14 | 1/2-14 | 0.031" |
| 0616-08-08-062 | 1/2-14 | 1/2-14 | 0.062" |

0696 Female Pipe Swivel Elbow Orifice Adapter



| Part Number | Male Pipe | Female Pipe Swivel | Orifice Dia. |
|----------------|-----------|--------------------|--------------|
| 0696-04-04-000 | 1/4-18 | 1/4-18 | Un-drilled |
| 0696-04-04-031 | 1/4-18 | 1/4-18 | 0.031" |
| 0696-04-04-062 | 1/4-18 | 1/4-18 | 0.062" |
| 0696-04-06-000 | 1/4-18 | 3/8-18 | Un-drilled |
| 0696-04-06-031 | 1/4-18 | 3/8-18 | 0.031" |
| 0696-04-06-062 | 1/4-18 | 3/8-18 | 0.062" |
| 0696-06-06-000 | 3/8-18 | 3/8-18 | Un-drilled |
| 0696-06-06-031 | 3/8-18 | 3/8-18 | 0.031" |

| | | | |
|----------------|--------|--------|------------|
| 0696-06-06-062 | 3/8-18 | 3/8-18 | 0.062" |
| 0696-06-08-000 | 3/8-18 | 1/2-14 | Un-drilled |
| 0696-06-08-031 | 3/8-18 | 1/2-14 | 0.031" |
| 0696-06-08-062 | 3/8-18 | 1/2-14 | 0.062" |
| 0696-08-08-000 | 1/2-14 | 1/2-14 | Un-drilled |
| 0696-08-08-031 | 1/2-14 | 1/2-14 | 0.031" |
| 0696-08-08-062 | 1/2-14 | 1/2-14 | 0.062" |

1115 O-Ring Boss JIC Orifice Adapter



| Part Number | Male ORB | Male JIC | Orifice Dia. |
|----------------|----------|----------|--------------|
| 1115-06-06-000 | 9/16-18 | 9/16-18 | Un-drilled |
| 1115-06-06-031 | 9/16-18 | 9/16-18 | 0.031" |
| 1115-06-06-062 | 9/16-18 | 9/16-18 | 0.062" |
| 1115-08-06-000 | 3/4-16 | 9/16-18 | Un-drilled |
| 1115-08-06-031 | 3/4-16 | 9/16-18 | 0.031" |
| 1115-08-06-062 | 3/4-16 | 9/16-18 | 0.062" |
| 1115-08-08-000 | 3/4-16 | 3/4-16 | Un-drilled |
| 1115-08-08-031 | 3/4-16 | 3/4-16 | 0.031" |
| 1115-08-08-062 | 3/4-16 | 3/4-16 | 0.062" |
| 1115-10-08-000 | 7/8-14 | 3/4-16 | Un-drilled |
| 1115-10-08-031 | 7/8-14 | 3/4-16 | 0.031" |
| 1115-10-08-062 | 7/8-14 | 3/4-16 | 0.062" |

1195 O-Ring Boss Elbow Orifice Adapter



| Part Number | Male ORB | Male JIC | Orifice Dia. |
|----------------|----------|----------|--------------|
| 1195-06-06-000 | 9/16-18 | 9/16-18 | Un-drilled |
| 1195-06-06-031 | 9/16-18 | 9/16-18 | 0.031" |
| 1195-06-06-062 | 9/16-18 | 9/16-18 | 0.062" |
| 1195-08-06-000 | 3/4-16 | 9/16-18 | Un-drilled |
| 1195-08-06-031 | 3/4-16 | 9/16-18 | 0.031" |
| 1195-08-06-062 | 3/4-16 | 9/16-18 | 0.062" |

1516 JIC Male to NPT Orifice Adapter



| Part Number | Male Pipe | Male JIC | Orifice Dia. |
|--------------------|------------------|-----------------|---------------------|
| 1516-06-04-000 | 3/8-18 | 7/16-20 | Un-drilled |
| 1516-06-04-031 | 3/8-18 | 7/16-20 | 0.031" |
| 1516-06-04-062 | 3/8-18 | 7/16-20 | 0.062" |
| 1516-06-06-000 | 3/8-18 | 9/16-18 | Un-drilled |
| 1516-06-06-031 | 3/8-18 | 9/16-18 | 0.031" |
| 1516-06-06-062 | 3/8-18 | 9/16-18 | 0.062" |
| 1516-08-08-000 | 1/2-14 | 3/4-16 | Un-drilled |
| 1516-08-08-031 | 1/2-14 | 3/4-16 | 0.031" |
| 1516-08-08-062 | 1/2-14 | 3/4-16 | 0.062" |